

CALIBRATION OF PROSHARP AS MACHINES

WWW.PROSHARP.COM



3. Release the emergency button (still hold the arrow buttons).

4. A lamp will shine above the buttons. (1 or 2 lights). And the light at the dress button will be red or yellow.

5. Release the buttons with the arrows.

6. Push one of the arrow buttons. 1 light will glow (2 lights for AS 2001)

7. Mount a skate in the machine and push the dress button.

8. The sled will start moving, without the wheel spins.

9. The sled will move for 8-10 cycles.

10. The sled stops and you will hear 3 beeps. The calibration is done!